


LISTE DE PIÈCES DE RECHANGE / LIST OF SPARES

Référence Item No	Description	Réf. rechange Spare part ref.	
1	Moteur <i>Motor</i>	HJ2386/01	
2	Circuit imprimé principal (motrice) + Lumière <i>Main PCB (motor coach) + Lights</i>	HJ2386/02	
3	Cardan, vis sans fin, carter supérieur et engrenages <i>Worm gear, cover, cardan shaft and gears</i>	HJ2386/03	
4	Bogie ensemble (motrice) <i>Complete bogie (motor coach)</i>	HJ2386/04	
5	Essieux avec engrenages <i>Wheels with gears</i>	HJ2386/05	
6	Bogie ensemble (remorque) <i>Complete bogie (non-driven coach)</i>	HJ2386/06	
7	Essieux sans engrenages <i>Wheels without gears</i>	HJ2386/07	
8	Bandages d'adhérence (2 pièces) <i>Traction tyres (2 parts)</i>	HJ2386/08	
9	Circuit imprimé principal (remorque) + Lumière <i>Main PCB (non-driven coach) + Lights</i>	HJ2386/09	
10	Circuit imprimé de lumière <i>Light PCB</i>	HJ2386/10	
11	Accessoires de carrosserie (motrice) <i>Bodyshell accesories (motor coach)</i>	HJ2386 HJ2387/88	HJ2386/11 HJ2387/11
12	Accessoires de carrosserie (remorque) <i>Bodyshell accesories (non-driven coach)</i>	HJ2386 HJ2387/88	HJ2386/12 HJ2387/12
13	Attelage pack <i>Coupler pack</i>		HJ2386/13

Installation d'un décodeur digital How to fit a decoder




Pour démonter la carrosserie:

- ① Déclipser la carrosserie ici.
- ② Retirez la carrosserie du châssis.

To open body:

- ① Unclip the bodyshell here.
- ② Remove the bodyshell from the chassis.



Lubrification du modèle / Lubricating the model

